



Shooting Board


Side View



Top View




End View




Use MDF for Board & fixtures and Hardwood for stops.
Glue & Screw parts together.

Edge Shooting Board


(for a left hand version move the 1/2" MDF to right side.)



Top View




Front View



Use MDF for Board & fixtures and Hardwood for stops.
Glue & Screw parts together.

Shooting Board Fixtures


45° Miter Fixture
MDF




Side View



45° Miter
'Bird House'
Fixture
MDF and Hardwood



Top View



Shooting Boards & Fixtures



Shooting Board



Edge Shooting Board



45° Miter Fixture



45° Miter 'Bird House' Fixture